

your remote control

IMPORTANT: The following diagram shows how to use the buttons on your remote control to operate the DVR and PIP functions on your Set-Top Box. To access these functions, set the remote control to its cable mode by pressing the [MODE] button, followed by the [CBL] button.

